

### 3-phase String Inverter-FAQ


## How to replace a 3 phase string inverter in iSolarCloud App

Applicable to: 3-phase string inverters


Before replacing an inverter, make sure you save/screenshot all customer and country specific parameters.

Open the iSolarCloud App on your mobile device.


Slide to **Device** and select the three dots, choose **Device Replacement**.



Select **+** to add the replacement device. Now, you can insert the new serial number by either scanning it from the **Barcode** at the new inverter or simply typing it in **manually**. After scanning/typing the serial number, confirm by clicking **START REPLACEMENT**.



After the successful change of the inverter, the new device will be shown in the device overview.



Make sure customer/country specific parameters are set according to the settings of the previous inverter.

For further information, please download the user manual [here](#).

This manual is intended for professional technicians who are responsible for installation, operation, maintenance and troubleshooting of inverters, and users who need to check inverter parameters. The inverter must only be installed by professional technicians.

The professional technician is required to meet the following requirements:

- Know electronic, electrical wiring and mechanical expertise, and be familiar with electrical and mechanical schematics.
- Have received professional training related to the installation, commissioning and troubleshooting of electrical equipment.
- Be able to quickly respond to hazards or emergencies that occur during installation, commissioning and troubleshooting.
- Be familiar with local standards and relevant safety regulations of electrical systems.
- Read this manual thoroughly and understand the safety instructions related to operations.