

Data Logger FAQ

How to log in on Logger1000-Web interface and update it

Applicable to: Logger1000

WiFi-login


Logger1000 supports WiFi-login. After the device is powered, check the SN code on the device and select the WiFi hotspot signal named SG-XXXX (XXXX is the device SN) to connect to WiFi.



Enter the default IP address of Logger 1000 in the browser address bar after the device is connected: **11.11.11.1** to open the device management interface, the initial password is **pw1111**.

Ethernet login


Logger 1000 also supports Ethernet login. The default IP address of Logger 1000 is **12.12.12.12**. First, after the device is powered, use the network cable to connect it with the computer, and change the IP address of the computer to make it in the same network segment as the device, as shown in the following figure.



Enter the default IP address of Logger 1000 in the browser address bar after the device is connected: **12.12.12.12** to open the device management interface, and the initial password is **pw11111**. After logging in, the main interface of Logger1000 is shown in the following figure.

System Update

Open **System**, click **System Maintenance** and select **System Update**. Choose **iSolarCloud Upgrade Package**. The Logger will now download the latest firmware and install it.



For further information, please download the user manual [here](#).

This manual is intended for professional technicians who are responsible for installation, operation, maintenance and troubleshooting of inverters, and users who need to check inverter parameters. The inverter must only be installed by professional technicians.

The professional technician is required to meet the following requirements:

- Know electronic, electrical wiring and mechanical expertise, and be familiar with electrical and mechanical schematics.
- Have received professional training related to the installation, commissioning and troubleshooting of electrical equipment.
- Be able to quickly respond to hazards or emergencies that occur during installation, commissioning and troubleshooting.
- Be familiar with local standards and relevant safety regulations of electrical systems.
- Read this manual thoroughly and understand the safety instructions related to operations.